



PI-108

PARTS LIST

Published in Oct.'02
5HH70770

NOTE

1.Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	5HH10010	LABEL/I	PI-108	60Hz	1

2.Service calls and freight will be charged separately.

Parts List

PI-108

— CONTENTS —

FIG.1	PI-108 (1).....	2
FIG.2	PI-108 (2).....	4
FIG.3	PI-108 (3).....	6
FIG.4	PI-108 (4).....	8
FIG.5	PI-108 (5).....	10
• INDEX		12

FIG. 1 PI-108 (1)

5HH




FIG. 1 PI-108 (1)

5HH

Ref.No.	Parts No.	Description	Standard parts
1	5C330600	PHOTO SENSOR	a-5A808380
2	5C610160	PAPER FEED TRAY	b-5BA07430
3	5C610270	FNS WIRING/2	c-5C331390
4	5HH10390	PAPER REGULATING PLATE/FRONT	d-5A808640
5	5HH10040	PAPER REGURATING PLATE/REAR	e-5A809700
6	5C610310	DRIVING BOARD ASSEMBLY	f-5A807450
7	5C610210	DOUBLE FEED PREVENTIVE SHEET/A	g-5A808350
8	5C610230	GUIDE SHAFT	h-5A808370
9	5A815350	PHOTO SENSOR(2)	
10	5C610290	OPERATION BOARD ASEMBLY	
11	5HH10330	OPERATION SHEET	
12	5HH10260	PAPER FEED COVER	
13	5C610170	COVER	
14	5HH10030	PAPER FEED BOARD	
15	5C610370	PINION	
16	5C610300	SIZE DETECTING BOSRD ASSEMBLY	
17	5C319330	LACK	
18	5C610330	PAPER FEED IDLER GEAR/A	
19	5A815330	RACK(Z=45)	
20	5HH10010	LABEL/I	
21	5HH10050	STACKING PART/2	

FIG. 2 PI-108 (2)

5HH




FIG. 2 PI-108 (2)

5HH

Ref.No.	Parts No.	Description	Standard parts
1	5A814700	PAPER FEED REVERSE GEAR(A)(Z=12)	a-5A807450
2	5C331120	REVERSAL ROLLER	b-5A807490
3	5C610200	DOUBLE FEED PREVENTIVE ROLLER	c-5A814730
4	5HH10270	DOUBLE FEED PREVENTING RUBBER	d-5A807440
5	5A814670	SEPARATE OSCILLATE SHAFT(LEFT)	e-5A807460
6	5A814680	LDLER GEAR(A)(Z=20)	f-5A808640
7	5A814690	PAPER FEED REVERSE GEAR(B)(Z=13)	g-5A809690
8	5A821360	TORQUE LIMITTER	
9	5A814630	SEPARATE OSCILLATE SHAFT(RIGHT)	
10	5A814320	STOPPER RING	
11	5A814660	SPACER(18X13)	
12	5C610180	DOUBLE FEED PREVENTIVE UNIT	
13	5C610110	DOUBLE FEED PREVENTIVE SPRING	
14	5A814600	OILLESS METAL	
15	5C610030	PAPER FEED GUID PLATE/A	
16	5C610120	PAPER FEED COVER PLATE	
17	5A811870	PIN (2X8)	
18	5C610090	PAPER LIFT-UP PLATE	
19	5C610100	REVERSAL SIDE PLATE	
20	5C610010	SEPARATE STANDARD PLATE	
21	5C610150	ACTUATOR	
22	5A814610	SEPARATE MT PLATE	
23	5A813970	PAPER LIFT UP PLATE	
24	5HH10290	PROTECT SHEET	
25	5HH10070	CONVEYANCE ROLLER/A	
26	5HH10090	CONVEYANCE GEAR/B	
27	5HH10180	ROLLING SHAFT HOLDER	
28	5A811670	PIN (A) (3X10)	
29	5HH10280	GUIDE SHEET /1	
30	5HH10300	GUIDE SHEET/2	

FIG. 3 PI-108 (3)

5HH




FIG. 3 PI-108 (3)

5HH

Ref.No.	Parts No.	Description	Standard parts
1	5C331110	FEEDING ROLLER/A	a-5A808640
2	5C610350	PAPER FEEDING ROLLER ASSEMBLY/A	b-5A810180
3	5HH10380	SHAFT STOPPER/4	c-5A807450
4	5HH10020	BELT REGULATING PART	d-5A809700
5	5HH10340	PULLEY/1	e-5A807440
6	5HH10190	SPACER/3	f-5A808630
7	5A814420	PAPER FEED DRIVE BELT(L=126)	g-5A821440
8	5HH10250	PAPER FEED ARM	
9	5HH10230	PAPER DETECTING ACTUATOR	
10	5C610340	FEDING ROLLER/B	
11	5C610360	PAPER FEEDING ROLLER ASSEMBLY/B	
12	5HH10140	RELEASE ARM	
13	5A824890	SHAFT FIXED MATERIAL	
14	5HH10150	SOLENOID ARM	
15	5HH10170	RELEASE SPRING/2	
16	5HH10130	RELEASE SHAFT HOLDER	
17	5HH10120	DRIVE POSITIONING PLATE/FRONT	
18	5HH10240	DRIVE POSITIONING PLATE/REAR	
19	5A814270	OILLESS METAL(A)	
20	5HH10310	FNS SOLENOID ASSEMNBLY	
21	5HH10160	SOLENOID MOUNTING PLATE/2	
22	5A807760	PHOTO SENSOR	
23	5HH10210	PAPER FEED GUIDE PLATE/B	
24	5HH10200	PAPER FEED FEEDING PLATE	
25	5HH10220	PAPER FEED GUIDE PLATE/C	
26	5HH10110	DRIVEN SPRING	
27	5HH10100	DRIVEN ROLLER	
28	5C330960	PIN (CLEANER A)	
29	5HH10320	PAPER DETECTING ACTUATOR/1	
30	5HC10220	SENSOR PRESSURE SPRING	




FIG. 4 PI-108 (4)

5HH

Ref.No.	Parts No.	Description	Standard parts
1	5A811470	METAL	a-5A807450
2	5HH10080	CONVEYANCE GEAR/A	b-5A807490
3	5A813790	PIN(A)(3X16)	c-5A808640
4	5A807760	PHOTO SENSOR	d-5C331570
5	5A814480	COUPLING	e-5A912130
6	5C610190	CLUTCH FIXED PLATE	f-5HA50010
7	5A814150	PAPER LIFT UP GEAR(C)(Z=15,70)	
8	5A814130	PAPER LIFT UP GEAR(B)(Z=63,14)	
9	5A814180	PAPER LIFT UP GEAR(A)(Z=12)	
10	5A814120	PAPER LIFT UP GEAR(D)(Z=40,15)	
11	5C610250	DRIVING GEAR/1(Z=50)	
12	5C610070	PRESSURE ROLLER	
13	5C610320	PAPER FEED CLUTCH	
14	5A813900	DOUBLE STEPPED GEAR(Z=34,17)	
15	5A813890	PAPER FEED REVERSE GEAR(Z=33)	
16	5C610240	PAPER FEED MOTOR ASSEMBLY	
17	5A812990	COLLAR	
18	5HH10370	CLEANER CLUTCH GEAR	
19	5HH10350	PAPER FEED DRIVING GEAR	
20	5HH10360	PARALLEL PIN	
21	5HH10060	SPACER	

FIG. 5 PI-108 (5)

5HH




FIG. 5 PI-108 (5)

5HH

Ref.No.	Parts No.	Description	Standard parts
1	5C610260	FNS WIRING/1	
2	5C610270	FNS WIRING/2	
3	5C610280	FNS WIRING/4	

INDEX

5HH

Parts No.	Description	Fig. No.	Parts No.	Description	Fig. No.
5A807760	PHOTO SENSOR	3,4	5C610120	PAPER FEED COVER PLATE	2
5A811470	METAL	4	5C610150	ACTUATOR	2
5A811670	PIN (A) (3X10)	2	5C610160	PAPER FEED TRAY	1
5A811870	PIN (2X8)	2	5C610170	COVER	1
5A812990	COLLAR	4	5C610180	DOUBLE FEED PREVENTIVE UNIT	2
5A813790	PIN(A)(3X16)	4	5C610190	CLUTCH FIXED PLATE	4
5A813890	PAPER FEED REVERSE GEAR(Z=33)	4	5C610200	DOUBLE FEED PREVENTIVE ROLLER	2
5A813900	DOUBLE STEPPED GEAR(Z=34,17)	4	5C610210	DOUBLE FEED PREVENTIVE SHEET/A	1
5A813970	PAPER LIFT UP PLATE	2	5C610230	GUIDE SHAFT	1
5A814120	PAPER LIFT UP GEAR(D)(Z=40,15)	4	5C610240	PAPER FEEED MOTOR ASSEMBLY	4
5A814130	PAPER LIFT UP GEAR(B)(Z=63,14)	4	5C610250	DRIVING GEAR/1(Z=50)	4
5A814150	PAPER LIFT UP GEAR(C)(Z=15,70)	4	5C610260	FNS WIRING/1	5
5A814180	PAPER LIFT UP GEAR(A)(Z=12)	4	5C610270	FNS WIRING/2	1,5
5A814270	OILLESS METAL(A)	3	5C610280	FNS WIRING/4	5
5A814320	STOPPER RING	2	5C610290	OPERATION BOARD ASEMBLY	1
5A814420	PAPER FEED DRIVE BELT(L=126)	3	5C610300	SIZE DETECTING BOSRD ASSEMBLY	1
5A814480	COUPLING	4	5C610310	DRIVING BOARD ASSEMBLY	1
5A814600	OILLESS METAL	2	5C610320	PAPER FEED CLUTCH	4
5A814610	SEPARATE MT PLATE	2	5C610330	PAPER FEED IDLER GEAR/A	1
5A814630	SEPARATE OSCILLATE SHAFT(RIGHT)	2	5C610340	FEDED ROLLER/B	3
5A814660	SPACER(18X13)	2	5C610350	PAPER FEEDING ROLLER ASSEMBLY/A	3
5A814670	SEPARATE OSCILLATE SHAFT(LEFT)	2	5C610360	PAPER FEEDING ROLLER ASSEMBLY/B	3
5A814680	LDLER GEAR(A)(Z=20)	2	5C610370	PINION	1
5A814690	PAPER FEED REVERSE GEAR(B)(Z=13)	2	5HC10220	SENSOR PRESSURE SPRING	3
5A814700	PAPER FEED REVERSE GEAR(A)(Z=12)	2	5HH10010	LABEL/I	1
5A815330	RACK(Z=45)	1	5HH10020	BELT REGULATING PART	3
5A815350	PHOTO SENSOR(2)	1	5HH10030	PAPER FEED BOARD	1
5A821360	TORQUE LIMITTER	2	5HH10040	PAPER REGURATING PLATE/REAR	1
5A824890	SHAFT FIXED MATERIAL	3	5HH10050	STACKING PART/2	1
5C319330	LACK	1	5HH10060	SPACER	4
5C330600	PHOTO SENSOR	1	5HH10070	CONVEYANCE ROLLER/A	2
5C330960	PIN (CLEANER A)	3	5HH10080	CONVEYANCE GEAR/A	4
5C331110	FEEDING ROLLER/A	3	5HH10090	CONVEYANCE GEAR/B	2
5C331120	REVERSAL ROLLER	2	5HH10100	DRIVEN ROLLER	3
5C610010	SEPARATE STANDARD PLATE	2	5HH10110	DRIVEN SPRING	3
5C610030	PAPER FEED GUID PLATE/A	2	5HH10120	DRIVE POSITIONING PLATE/FRONT	3
5C610070	PRESSURE ROLLER	4	5HH10130	RELEASE SHAFT HOLDER	3
5C610090	PAPER LIFT-UP PLATE	2	5HH10140	RELEASE ARM	3
5C610100	REVERSAL SIDE PLATE	2	5HH10150	SOLENOID ARM	3
5C610110	DOUBLE FEED PREVENTIVE SPRING	2	5HH10160	SOLENOID MOUNTING PLATE/2	3

Parts No.	Description	Fig. No.
5HH10170	RELEASE SPRING/2	3
5HH10180	ROLLING SHAFT HOLDER	2
5HH10190	SPACER/3	3
5HH10200	PAPER FEED FEEDING PLATE	3
5HH10210	PAPER FEED GUIDE PLATE/B	3
5HH10220	PAPER FEED GUIDE PLATE/C	3
5HH10230	PAPER DETECTING ACTUATOR	3
5HH10240	DRIVE POSITIONING PLATE/REAR	3
5HH10250	PAPER FEED ARM	3
5HH10260	PAPER FEED COVER	1
5HH10270	DOUBLE FEED PREVENTING RUBBER	2
5HH10280	GUIDE SHEET /1	2
5HH10290	PROTECT SHEET	2
5HH10300	GUIDE SHEET/2	2
5HH10310	FNS SOLENOID ASSEMNBLY	3
5HH10320	PAPER DETECTING ACTUATOR/1	3
5HH10330	OPERATION SHEET	1
5HH10340	PULLEY/1	3
5HH10350	PAPER FEED DRIVING GEAR	4
5HH10360	PARALLEL PIN	4
5HH10370	CLEANER CLUTCH GEAR	4
5HH10380	SHAFT STOPPER/4	3
5HH10390	PAPER REGULATING PLATE/FRONT	1

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Show Room:

1410 Broadway 23rd floor
New York, NY 10018
TEL : (917) 286-5400
FAX : (917) 286-5402

Northeastern Region:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 570-4704

Dallas Parts Distribution Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
02130 Azcapotzalco
México, D.F. México
TEL : (55) 383-2741
FAX : (55) 383-7804

© 2002 KYOCERA MITA CORPORATION

 **KYOCERA** is a trademark of Kyocera Corporation

Printed in U.S.A.

mita is a registered trademark of KYOCERA MITA CORPORATION